

製品番号 811 365

## 取扱説明書


ワイヤレス ポケボール スピーカー




### 特徴

- ・ 内容品；ポケボールスピーカー、マイクロ USB ケーブル
- ・ Bluetooth バージョン 4.2（周波 2.402-2.480G）
- ・ 作動距離 10m+/感度；83dB
- ・ リチウムバッテリー 3.7V/1200Ah
- ・ 充電時間 3-4 時間/稼働時間 4 時間（音量による）

### 使用ボタン



- ① TF インターフェイス-最大 32G/MP3、WMA、APE、FLAC 音楽ファイル対応。
- ② ON/OFF ボタン
- ③ DC5V 充電ポート-マイクロ USB ケーブルでコンピュータ接続
- ④ **Vol - /** 一回押すと音量を下げ、長押しで前のトラックへ
- ⑤ **Vol + /** 一回押すと音量を上げ、長押しで次のトラックへ
- ⑥ Line-in-携帯電話、MP3 プレイヤー-コンピュータやタブレットなど外部オーディオ接続。DC3.5,,m m（非付属）
- ⑦ 再生/一時停止ボタン 点滅-再生中、点灯-音楽再生中または充電中



## 製品を安全にお使いいただくために

- ・電気ショックや窒息を防ぐために子供の手の届かないところにおいてください
- ・どんな液体も製品にこぼさないでください。また電気ショックを避けるため濡れた手での操作はしないでください。
- ・製品を分解したり、修理または再構築しないでください。
- ・キャンドルなどの火災源を近くやスピーカの上に置かないでください。
- ・スピーカーやコードをヒーターや直射日光など熱源装置にさらさないでください。
- ・以下の場合には使用を中止してください；高温、煙、焦げた香り、聞きなれない動作音がある場合。また製品の使用に違和感を感じた時。

## 保障

こちらの製品の保証期間は2年です。お買い上げいただいた販売店様の販売印・お買い上げ年月日を必ずご確認ください。

誤った誤使用や不注意による故障または損傷、天災地変等による故障または損傷などには対応しておりません。

\*取扱説明書は大切に保管してください。重要な情報が含まれております。

*Teknofun states that this product complies with the essential requirements and other relevant provisions of directive 2014/53/UE. The declaration of conformity can be requested at [hotline@teknofun-entertainment.eu](mailto:hotline@teknofun-entertainment.eu) or 15 rue beaujon 75008 PARIS France*

Made in RPC

© 2017 Teknofun All Rights reserved

© 2017 Madcow Entertainment France All Rights reserved

<http://www.teknofun-entertainment.com>

©2017 The Pokémon Company International. ©1995–2017 Nintendo/Creatures Inc./GAME

FREAK inc. TM<sup>®</sup>, and character names are trademarks of Nintendo.